User Manual

SPOTTER™

GPS NAVIGATOR

Dale Jr™ EDITION

88
amp ENERGY
IMPALA SS
mtn DEW
NATIONAL GUARD

RightWay®

Model RW500

DALE JR 88
SPOTTER
GPS NAVIGATOR
88
DALE JR
RightWay
NAVTEQ ON BOARD
POWERED BY COPILOT
RightWay
NASCAR

Welcome!

Congratulations and thank you for choosing the ***SPOTTER*** GPS Navigator, Dale Jr. edition!

We hope you enjoy using this exciting product and trust that it will make your driving experience more fun and entertaining.

This guide will tell you everything you need to know about using your ***SPOTTER*** GPS Navigator. It will explain the basics, share some tips for operation and show you how to customize your ***SPOTTER***. The following symbols refer to specific passages you should be aware:

⚠ The caution symbol highlights items related to your safety and well-being. Please read and pay close attention to these warnings.

❗ The exclamation point highlights helpful hints and tips for operation.

TABLE OF CONTENTS

GETTING STARTED ***6***

DALE JR. EDITION SPECIAL FEATURES ***7***
- **SELECT the GPS Pointer** **7**
- **Dale Jr.'s Voice** **7**
- **Race Shop Tour Route** **8**
- **Unique Points of Interest** **8**
  - *Dale's favorite's* *8*
  - *NASCAR* *8*

BASIC OPERATIONS ***9***
- ***SPOTTER*** **GPS Hardware** **9**
- **Mounting Your Device** **10**
  - *Attaching the Mount* *10*
  - *detaching the Mount* *11*
- **Power** **12**
  - *Battery Status Icon* *12*
  - *Charging the Battery* *12*
- **The *SPOTTER* can be used for navigation while the unit is recharging.** **12**
- **Programs Window Overview** **13**

NAVIGATION ***14***
- **Tips & Tricks** **14**
- **GPS Start Up** **15**

- **First Trip** **16**
  - *Selecting a destination* *16*
  - *More* *17*

- **On the Move** **19**
  - *Change the GPS Pointer* *19*
  - *Change the voice* *19*
  - *Change the driving view* *19*
  - *Make a Detour* *20*
  - *Search for a Point of Interest* *20*

- **In Use** **21**
  - *Selecting multiple stops for your trip* *21*
  - *Customizing your trip* *21*
  - *Setting waypoints* *22*
  - *Saving destinations in your trip as favorites* *22*
  - *Saving a trip* *23*
  - *Loading a saved trip* *23*
  - *Deleting a planned trip* *23*
  - *Preview your route* *23*
  - *Setting Routing options for your trip* *24*
  - *Preview Options for your trip* *25*
  - *Guidance* *26*
  - *Driving views* *26*

ETA and distance *27*
Nearby points of interest *27*

Personalize **29**
Saving a destination as Home *29*
Saving a destination as Work *29*
Save your Favorite destinations *30*
Edit or delete Favorites *30*
To choose a recent destination *30*
Other ways to select a destination *31*
To delete the recent list *31*
To choose an Intersection as a destination *31*
Setting display mode *31*
Selecting the language & voice guide *31*
Customizing the guidance screen *32*
Setting Map Styles *32*
Customizing routing options *32*

Display Screen Options **33**
Driver Safety view *33*
3D view *33*
2D Where Am I *33*
2D Next Turn *34*
2D Destination *34*
Itinerary *34*
Night mode *35*

Advanced **36**
Advanced POI Search *36*
Adjusting the POI settings *37*
Selecting a destination using Lat and Long *37*
Setting detours *38*
Ending a Detour *38*
Optimizing stops *38*
Enable Fuel Calculator *39*
Change your entire trip *39*
Setting map preferences *39*
Setting Map Styles *40*
Setting route preferences *40*
Saving a route preference *41*
Loading a saved routing profile *41*
Edit your road preferences *41*
Checking the GPS status *41*
Adjusting your Safety View *42*
Track Playback *42*
Adjusting the volume *43*
Setting the Language and Speech *43*
Adjusting Keyboard Settings *44*
Playing a demo *44*

MULTI-MEDIA FEATURES ***45***
Memory Card **46**
Inserting a Memory Card *46*
Removing a Memory Card *46*
Movie Viewer **47**
Music Player **48**
E-Book Reader **49**

Bookmark ... *50*
Jump to the appointed page ... *50*
Search for specific word or phrase ... *51*
Photo Viewer ... **52**

SETTINGS MENU ... ***53***
Language ... *53*
Backlight ... *53*
Power ... *53*
Sound ... *53*
Time ... *53*
System ... *53*

FREQUENTLY ASKED QUESTIONS ... ***54***

TECHNICAL SPECIFICATIONS ... ***55***

SAFETY & WARRANTY INFORMATION ... ***56***
Safety Information ... **56**
Care & Safe Keeping oF the *SPOTTER* GPS ... **56**
Liability ... **57**
End User's License Agreement ... **57**
Transplant GPS, Inc. Limited Warranty ... **60**
FCC Part 15 Compliance Statement ... **61**

CUSTOMER SERVICE ... ***62***

GETTING STARTED

Your ***SPOTTER*** GPS Navigator comes with the following accessories. If your box is incomplete, please notify us **within 14 days of purchase**. The purchased products include:

- ***SPOTTER*** GPS Navigator, Dale Jr. edition
- Car charger
- Mounting system
- Quick Start Guide
- User Manual

DALE JR. 88
CoPilot Live
Destination
Favorites
Settings
Drive
No destination
Welcome to CoPilot
MENU
NASCAR

The Dale Jr. edition of the ***SPOTTER*** GPS Navigator comes with some bonus materials which include:

- Photo of Dale Earnhardt Jr.
- SD card with photos and video clips
- Exclusive savings from NASCAR.com, JR Motorsports, and many others

DALE JR. EDITION SPECIAL FEATURES

SELECT THE GPS POINTER

There are 4 GPS pointers from which to choose: the Amp Energy Car, the National Guard Car, the Team Hauler or the traditional arrow head. To change the GPS Pointer, select

- **Menu>Setting> GPS Pointer**
- **T**ap the vehicle of your choice, then OK.


GPS Pointer
○ Amp Car (Default)
○ Arrow
○ National Guard Car
○ Transporter
Cancel
OK

DALE JR.'S VOICE

Forget the formal computer generated voices, hear directions and commentary like Dale was sitting in the seat next to you.

> **NOTE:** Dale's voice does not speak street names. To access voices which will speak street names, please see page 43.


Language and Speech
Test
Cancel
OK

Choose a Language: US English

Choose A Voice: Dale Jr

*=Full-text voices which will speak street names.

RACE SHOP TOUR ROUTE

The ***SPOTTER*** comes pre-loaded with a Race Shop Tour Route which includes 14 garages and race shops in the Charlotte, NC area. The route will begin with your current location and provide the most efficient route to visiting all the garages.


Plan Trip
Add Stop
Optimize
Options
Clear
Save Trip
Load Trip
Calculate

Earnhardt Ganassi Racing
Cox Mill, NC

Hendrick Motorsports
Harrisburg, NC

JR Motorsports
Mooresville, NC

Penske Racing South
Mooresville, NC

Richard Petty Motorsports
Celeste Hinkle, NC

To open the NASCAR Garage Tour Route, tap **Menu> Arrow> Plan or Edit Trip> Load Trip> Select NASCAR Garage Tour.trp> Hit OPEN> Calculate**

For more information on routing, please see page 41.

UNIQUE POINTS OF INTEREST

DALE'S FAVORITE'S

A special POI category has been added, Dale's Favorites, with a list of places he likes to visit, businesses he owns, and places that are just too cool to miss. He even provides a little additional commentary on some of the stop.


Select a POI
Cancel
Back
Add Stop
Details
More

Mooresville High School	24.4
Scrap Shack	24.5
Pie in the Sky Pizza	24.6
Village Inn Pizza of Mooresville	25.8
JR Motorsports	26.3

NASCAR

NASCAR is the other POI category created just for race fans. It includes all the NASCAR Home Tracks,™ NASCAR Speed Parks,™ NASCAR Sprint Cup Series™ tracks and team garages.

For more information on POIs, please see pages 20, 36 and 37.


Select a POI Category
Dale Jr
NASCAR
Airport
Attractions
Auto Dealership
Bank
Bridges & Tunnels
Bus/Taxi/Limo
Custom
Entertainment
Event Facility

BASIC OPERATIONS

SPOTTER GPS HARDWARE


Stylus
Sleep
Menu
Power
Headphone Jack
Charging Port
USB Port*
SD Card Slot

Button	Function
Power	turn unit on or off
Menu	return to the main menu from any screen
Sleep	low power consumption mode for when unit is on but not in use

* The USB port will *not* charge the device or sync with a computer or other electronic devices. It is reserved for potential future use in upgrades.

MOUNTING YOUR DEVICE

Your ***SPOTTER*** GPS Navigator can be easily secured to either the windshield or the dashboard for optimal viewing while driving. The mounting system consists of the following pieces:

- Adjustable arm with suction cup
- ***SPOTTER*** cradle
- Dash disk with adhesive backing

ATTACHING THE MOUNT

1. Select a location for the mount on the windshield or dashboard that does not obstruct the driver’s view or interfere with the operation of the vehicle.

2. Clean and dry this area to remove any grease and dirt.

   If mounting the ***SPOTTER*** on the dashboard, remove the protective backing from the dash disc, exposing the adhesive. Adhere the disc to the dashboard in the desired location.

   The adhesive is permanent.

3. Place the suction cup on the desired location on the windshield or dash disc; push the locking lever towards the base of the mount. The mount should stick to the surface.

   If your mount does not stick, make sure the area is clean and dry, then try again.



4. Align the tabs on the adjustable arm with the slots on the ***SPOTTER*** cradle. Slide together until you feel a firm click.

5. Adjust the holder to the best viewing angle by:
   a. Loosening the adjustor dials
   b. Moving the corresponding part to the desired position
   c. Tightening the adjustor dials.

6. Align the grooves on the bottom of your unit with the tabs on the bottom of the ***SPOTTER*** cradle; gently push the unit into the cradle until the unit clicks into place.

7. To remove the ***SPOTTER*** from the mount, gently push back the tab on the top of the cradle until you hear a click releasing the unit.

DETACHING THE MOUNT

1. Pull the locking lever away from the base of the mount.

2. Grasp the pull tab of the suction cup and gently pull away from the windshield or dash to break the suction.

⚠ **Caution!**
It is illegal in Minnesota to attach anything to the windshield.

When using navigation aids in a vehicle, it is your sole responsibility to place, secure and use these aids in a manner that will not cause accidents, personal injury, property damage, or in any manner to obstruct your view. You, the user of this product, are solely responsible for observing safe driving practices.

POWER

BATTERY STATUS ICON

Full → Drained

BATTERY LIFE

The actual life of the battery depends on usage. On average, a fully charged battery will last 3 hours working and 180 hours in sleep mode.

CHARGING THE BATTERY

The ***SPOTTER*** GPS Navigator comes with a charged battery and is ready to use straight out of the box. When the internal battery needs to be re-charged, this is done through a car charger. (AC chargers are available at RightWayGPS.com.)

A completely drained battery will fully charge in 4 hours. Actual charging time varies depending on how drained the battery was and usage while charging.

1. Insert the small end of the car charger cable into the charging port of the ***SPOTTER***. (Note: The USB port cannot be used for charging.)
2. Plug the larger end of the car charging cable into the jack of the cigarette lighter.
3. Battery charging begins. While charging, the indicator light will be red. When the battery is fully charged, the red light will go off.

The ***SPOTTER*** can be used for navigation while the unit is recharging.



Battery Charging Indicator Light

PROGRAMS WINDOW OVERVIEW

The PROGRAMS WINDOW of the ***SPOTTER*** GPS Navigator contains five programs – navigation, music player, movie player, e-book reader, and photo viewer – as well as settings which can be changed.

To start any of these programs, tap on the icon.*


GPS
08:36
GPS
Video
Music
Picture
E-Book
System Set

*Icons are subject to change, but the programs will remain the same.

NAVIGATION

To begin navigation, tap the 'Navigation' button. A blue indicator light will go on indicating the navigation software is running. The blue light will remain on as long as the navigation software is running.


Navigation Indicator Light
DALE JR 88
NASCAR

A screen will appear with a safety warning. Tap 'Accept' and the main navigation window will open.


Warning
Accept

Using this product while driving can be distracting and dangerous.
Please exercise caution and common sense in its use and operation.

TIPS & TRICKS

The ***SPOTTER*** GPS Navigator has many great features. To help you get to know them, we have included a Tips & Tricks at start up.


Tips and Tricks
☑ Show Tips and Tricks

You can choose a variety of Map views including 3D and 2D.

Select Menu > Driving Views

To see more Tips & Tricks, use the arrows.
To turn off Tips & Tricks, uncheck the 'Show Tips & Tricks' box.
Click on the white X in the red circle to close the window.

GPS START UP

The ***SPOTTER*** GPS Navigator has an integrated GPS receiver. The first time you use the GPS receiver it may take up to 10 minutes to initialize. After the first time, GPS reception should start within one minute of turning on the device. If the navigation device has been switched off for more than a week, the next initialization can take up to 5 minutes.

GPS Signals
GPS signals are limited inside buildings, tunnels, and parking ramps. To work most effectively, mount the ***SPOTTER*** on the windshield for clear line of sight to the sky.

To ensure ETA to your destination is accurate, select the correct time zone.
From the Welcome menu

- Tap **Settings > Next > Next > Time Zone**.
- Select the time zone of your current location
- Select Daylight savings (optional)

Do NOT remove the SD card
while operating the *SPOTTER* GPS Navigator!

FIRST TRIP

SELECTING A DESTINATION

The ***SPOTTER*** uses GPS satellites to calculate your exact position so you don't have to enter your starting point. Simply enter your destination and the ***SPOTTER*** will take you there, providing detailed turn instructions all the way.

- Tap **Menu > Destination > Address**.
- Enter the city or town name of your destination.
- Select the correct city or area when it appears in the list below. Scroll down to see more address options matching what you have typed.



Eas

East Atherton Street

East Corey Street

Cancel
Back
Expand
1 2 3 4 5 6 7 8 9 0
q w e r t y u i o p
a s d f g h j k l @
_ z x c v b n m , .
- !
123

- Enter the first three or four letters of the street name. Select the correct street name when it appears in the list below the street name field.
- Enter the house number and select Finish, or just select Finish to skip this step.

A screen will then appear, showing you a map of the route. Select **Drive** to begin navigating your route.



Trip: 9.1 mi, 0:17 hr

Route
Routing
Preview
Edit
Drive
52
14
Rochest

Quick Destination Entry
You can select a destination from the map.

- Click on **Menu > Destination > Next** arrow and select **Pick on Map**.
- A map of the area around your current location will be displayed.
- Touch the screen to move around the map and tap your desired destination when you find it.

MORE…

There's more you can do when entering your destination and setting off.
Here are some helpful page references in this Guide:

- Plan a trip with multiple destinations, waypoints or optimize your trip – page 21.


Plan Trip
Add Stop
Optimize
Options
Clear
Save Trip
Load Trip
Calculate

Lower Makefield, PA 19067

Pitt Marie
Princeton, NJ

Dumont & Watson
184 Alexander Street
Princeton, NJ

1st Street & Sunset Drive
Gaithersburg, MD 20882

50 Barker Street
Mount Kisco, NY 10549

- Set and save Work and Home addresses for quick and easy route planning – page 29.


Address
Points of Interest
Home
Work
Favorites
Destination (1 of 2)

- Create and manage your favorite destinations – page 30.


Manage Favorites
9 Glen Mawr Drive
50 Barker Street
Dumont & Watson*
1st Street & Sunset Drive
Pitt Marie*
Edit
Delete
Delete All

- Choose to see an itinerary list of your route, a map of each turn, or a demo of the whole route – page 23.


Route Demo
Turn Maps
Itinerary
Route Preview

ON THE MOVE

CHANGE THE GPS POINTER

There are 4 GPS pointers from which to choose. Select **Menu>Setting> GPS Pointer**.

Tap on the vehicle of your choice, then tap OK.


GPS Pointer
○ Amp Car (Default)
○ Arrow
○ National Guard Car
○ Transporter
Cancel
OK

CHANGE THE VOICE

The default voice setting is Dale Jr.'s voice. In addition to Dale's voice, there are multiple voices from which to choose. Select **Menu>Settings>Next> Next> Language & Speech**.

Learn more about the voice options on page 43.


Language and Speech
Test
Cancel
OK

Choose a Language: US English

Choose A Voice: Dale Jr

*=Full-text voices which will speak street names.

CHANGE THE DRIVING VIEW

There are multiple driving views to choose from. Simply select **Menu > Next>Driving Views**.

Learn more about the different driving views – pages 33-35.


Driver Safety
3D
2D Where Am I
2D Next Turn
2D Destination
Driving Views (1 of 2)

MAKE A DETOUR

Make a detour from your current itinerary. You can choose an alternate route, or just detour around a section of the route. Select **Menu > Detour**.

Learn about the different detour options – pages 20.


Alternate Route
End Detour
Avoid Roads
Clear Avoided Roads
Detour

SEARCH FOR A POINT OF INTEREST

If you are running low on gas, need a hotel or nearby restaurant, tap **Menu > Nearby POI** to search for what you need.

Learn more about searching for POIs- pages 36.


Select a POI Category
Dale Jr
NASCAR
Airport
Attractions
Auto Dealership
Bank
Bridges & Tunnels
Bus/Taxi/Limo
Custom
Entertainment
Event Facility

Do not attempt to change the settings, or set a destination while you are driving. Ask a passenger to make changes, or pull over safely.

Do not leave your PND loose in the car while driving. Ensure it is correctly seated in your windshield mount. See page 10 for instructions.

IN USE

SELECTING MULTIPLE STOPS FOR YOUR TRIP

The ***SPOTTER*** GPS Navigator allows you to plan a trip with multiple destinations.

- Tap **Menu**, scroll to the next page and tap **Plan or Edit Trip**.
- Tap **Add Stop** and choose **Address**.
- Add the first address in the same way as detailed above; see **Selecting A Destination** on page 16.
- Tap **Add Stop** again to add your second, third, fourth, etc. address.



Lower Makefield, PA 19067

Pitt Marie
Princeton, NJ

Dumont & Watson
184 Alexander Street
Princeton, NJ

1st Street & Sunset Drive
Gaithersburg, MD 20882

50 Barker Street
Mount Kisco, NY 10549

CUSTOMIZING YOUR TRIP

When you have entered all your stops you can change the order they appear in.

- Tap the address you wish to move.
- A pop-up menu will appear containing a list of options: Tap **Move Up, Move Down, Move to Start** or **Move to End**.
- The selected stop will move to its new position in the trip list.

Show on Map
If you select **Show on Map** from the pop-up menu, a map of the area around the selected stop will be displayed. Click the white X in the red circle to return to the trip list.

The ***SPOTTER*** also has an Optimize Stops function to find the most efficient route. For more details see **Optimizing stops** on page 38.

SETTING WAYPOINTS

You can route through a certain point without considering it as a stop. By setting **Waypoints** you can adjust the route, to calculate a detour via the waypoint.

- Select **Menu > Next> Plan or Edit Trip**. Enter the address or place in the same way detailed in **Selecting a Destination** on page 16.
- The address will appear on the trip list as a Stop, with a flag icon next to it. Tap on the address you wish to change to a Waypoint.
- A pop-up menu will appear containing a list of options. Tap **Set as Waypoint**. The address will now be listed as a Waypoint, with an arrow icon in front of the address or place to indicate that is it a Waypoint.

Make a Waypoint a Stop
To change a Waypoint back to a Stop, tap the address and select **Set as Stop** from the pop-up menu.

SAVING DESTINATIONS IN YOUR TRIP AS FAVORITES

You can save addresses listed on the trip list as Favorite destinations so you can access them quickly.

- Tap on the address you wish to save as a favorite.
- A pop-up menu will appear containing a list of options. Tap **Add to Favorites**.


Plan Trip
Lower Makefiel
Pitt Marie
Princeton, NJ
Dumont & Wats
184 Alexander
Princeton, NJ
1st Street & Su
Gaithersburg, M
Delete
Set As Waypoint
Show on Map
Move to Start
Move Up
Move Down
Move to End
Add to Favorites
Add Stop
Optimize
Options
Clear
Save Trip
Load Trip
Calculate

Do more with Favorites.
For more information on Favorites see page 30.

SAVING A TRIP

When you have finished entering all your addresses, you can save your trip to access at a later date, rather than start driving right away.

- Tap **Save Trip**.
- Enter a name for the trip you are saving.
- Tap **Save** and the trip will be saved to the memory card.

LOADING A SAVED TRIP

- Tap **Menu,** scroll to the next page and tap **Plan or Edit Trip**.
- The last trip you planned will automatically load. If you wish to load an older trip, tap **Load Trip** and select the trip you wish to load from the list.

DELETING A PLANNED TRIP

- Tap **Clear**.
- You will be asked to confirm this selection. To continue with deleting the trip, tap **Yes** in the **Are you Sure**? Window.

PREVIEW YOUR ROUTE

Once a multi-stop trip has been entered, press **Calculate** then a route screen will appear, showing you a preview map of the route.


Route
Lenoir
901
Lexington
Hickory
Salisbury
10
152
Lincolnton
73
Concord
740
Shelby
27
Charlotte
205
731
Routing
Preview
Edit
Drive

Trip: 212.2 mi, 4:51 hr

SETTING ROUTING OPTIONS FOR YOUR TRIP

Select **Settings> Routing** to change the routing options for your trip. The available settings are:

- **Vehicle type**: Choose from Automobile, RV, Motorcycle, Bicycle, Walking or Straight Line.
- **RV Height Restrictions**: Chose from a variety of heights to accommodate your vehicle.
- **Routing type**: Choose whether you want to always choose the route quickest in time or the shortest in distance, avoid expressways or a scenic route.
- **Routing profile**: Choose from Default routing or a routing profile previously created and saved.



Vehicle Type: Automobile
RV Height Restriction: 12 feet 6 inches
Routing Type: Quickest
Toll Roads: Use

General

☐ Scenic Route
☐ Avoid Ferries
☐ Avoid Propane Restricted Tunnels
☑ International Borders Open

Tap **OK** to apply your routing preferences. For more information on how to save a routing profile - pages 40-41.

PREVIEW OPTIONS FOR YOUR TRIP

Select **Preview** to see the preview options for your journey.


Route Demo
Turn Maps
Itinerary
Route Preview

- **Route Demo**: See a preview of your trip, including instructions. You can choose to speed up the demo with **Faster** or slow it down by tapping **Slower**. Tap **Close** to exit.

- **Turn Maps**: Displays a map of each turn of the trip. You can choose to see the **Next** or **Previous** turn. Tap **Close** to exit.

- **Itinerary**: Shows each direction in a written list with distance to the turn. Tap **Close** to exit.

- Select **Drive** to begin navigating your route.

Starting points

If you are planning a trip in advance and are not at the start point of your trip, the ***SPOTTER*** will ask you to select your starting location. You can choose to navigate to the starting point, or to navigate directly to the destination from your current location.


You are not currently at the start location of your trip. Where do you want to go next?

● 50 Barker Street
Mount Kisco, NY 10549

○ 9 Glen Mawr Drive
Ewing, NJ 08618

Go
Austin Dr
Raab Drive
Unnamed Road
MENU
Del Rio Drive
ETA
DISTANCE

GUIDANCE

The ***SPOTTER*** GPS Navigator will guide you to your destination with clear visual instructions and spoken instructions. Whenever you are approaching your next turn, the ***SPOTTER*** will speak to you to alert you to the upcoming direction change.



Stay on US-206 South (Stockton Street) as it turns right

ETA
2:41 a
DISTANCE
12.3 mi
3.1
mi
MENU
18 mph
12.3 mi

DRIVING VIEWS

You can choose from six different screen display options. To access, tap **Menu > Next> Driving Views**. In the default mode, your screen will look like the one below.

For more details on each view see **Setting Display Mode** on page 31.

Zoom In **Zoom Out**



Terhune
Mount Lucas Road
aurel
Redhill Road
ETA
2:39 a
DISTANCE
10.6 mi
1.4
mi
US-206 South (Stockton Street)
MENU
18 mph
10.6 mi

Take a closer look
Use the **+** and **-** in 2D or 3D driving view to zoom in or out of the map view.

ETA AND DISTANCE

The estimated time of arrival (ETA) and the distance remaining are displayed on the right of the screen, no matter which driving view you have selected. You can choose what useful information is displayed at the bottom of your screen when you are driving, please see **Customizing the guidance screen** on page 32.


Destination
Current Road
Next Crossroad
Next Major Road
Nearest Town
ETA & Distance
Speed & Distance
Altitude & Heading
Latitude & Longitude
ETA
12:02 a
DISTANCE
496 mi
0.9
mi
Exit 362 - Keel
MENU
Hwy 401 (Macdonald-Cartier Freeway...

NEARBY POINTS OF INTEREST

If you're running low on gas, looking for a hotel or you want a bite to eat, CoPilot has millions of pre-loaded Points of Interest (POIs) to search.

- **Select Menu > Nearby POI**.


Select a POI Category
Dale Jr
NASCAR
Airport
Attractions
Auto Dealership
Bank
Bridges & Tunnels
Bus/Taxi/Limo
Custom
Entertainment
Event Facility

- From the list, select a category. For example, Restaurant.
- After a few moments a list of the nearest restaurants will appear, in order of distance from your current location.
- Select the restaurant you wish to visit and tap **OK**. A preview map of the route to your selected POI will appear.
- Tap **Drive** to begin navigating the route.

Widen your search
The ***SPOTTER*** GPS Navigator will list the POIs within a ten mile radius of your current GPS position, to increase the radius by another ten miles tap **More**.

POI in the city
You can search for a POI within a city, near your current location or along your route by pressing **Destination > POI Search**. You can search for a particular POI within a category, by name.

For more details, see **Advanced POI Search** on page 36.

PERSONALIZE

Enter and save personal destinations, change the map style and color theme, adjust your routing options, and select the voice that guides you to your destination. With the ***SPOTTER*** you can personalize your device to behave exactly the way you need.

SAVING A DESTINATION AS HOME

Save your home address so you don't have to enter it every time you wish to be directed home.

- **Menu > Destination > Home**.
- Enter your home city/town name.
- Select the correct city or area when it appears in the list below the city field. Scroll down to see more address options matching what you have typed.
- Enter your street name. As you enter the street name the ***SPOTTER*** will list potential matches. Select the correct street name when it appears in the list below.
- Enter your house number and select **Finish**, or just select **Finish** to skip this step.

SAVING A DESTINATION AS WORK

Save your work address so you don't have to enter it every time you wish to be directed to work.

- Tap **Menu > Destination > Work**.
- Enter your work city/town name.
- Select the correct city or area when it appears in the list below the city field. Scroll down to see more address options matching what you have typed.
- Enter the street name. As you enter the street name the ***SPOTTER*** will list potential matches. Select the correct street name when it appears in the list below.
- Enter your office number and select **Finish**, or just select **Finish** to skip this step.

SAVE YOUR FAVORITE DESTINATIONS

You can save other addresses to your Favorites list, so you can access them quickly.

- Tap **Menu > Destination > Favorites**.
- Tap **Add New** and it will return to the Destination menu.
- Choose to add the favorite by inputting the address or zip code (tap Address) or by locating it on a map (Pick on Map).
- When you've successfully added the address or location, it will appear in your Favorites list.

EDIT OR DELETE FAVORITES

To edit or delete a location in your Favorites list, tap Manage, select a location and choose to **Edit, Delete or Delete All**.

- Edit will open an enter address screen so you can change the location.



Jr Motorsports

Set this address as Other

Mooresville, NC

- Delete will erase the currently highlighted location.
- Delete all will erase all the locations in your Favorites list. Including your Home and Work addresses.

  NOTE: You will be asked to confirm if you wish to delete an item. If you select Yes the address will be lost.

TO CHOOSE A RECENT DESTINATION

Select **Menu > Destination > Recent** provides quick and easy access to the last 50 destinations that you entered.

Note: Your recent list will store the last 50 addresses you have entered. When the list is full each new address will replace an older inactive address.

OTHER WAYS TO SELECT A DESTINATION

The ***SPOTTER*** GPS Navigator offers a variety of ways to select a destination. You can save locations as Home and Work for one click route finding, see previous page.

In addition the ***SPOTTER*** let's you **Pick on Map**, **Search for a Point Of Interest** (POI), and select from **Favorite** or **Recent destinations**.

TO DELETE THE RECENT LIST

Select **Menu > Destination > Next> Recent > Clear All**

TO CHOOSE AN INTERSECTION AS A DESTINATION

- Select **Menu > Destination > Next> Intersection**.
- Enter the City or Town and click next, you will be asked to enter the first road and then the second. The ***SPOTTER*** will calculate your route to the point where they meet.

SETTING DISPLAY MODE

You can choose from six different screen display options. To access tap **Menu > Next> Driving Views**. For more details see pages 33-35.

SELECTING THE LANGUAGE & VOICE GUIDE

You can alter the voice with which the guidance instructions are spoken. For more detail on altering the **Language and Speech options** see page 43.

- Tap **Menu > Settings > Next> Next>Language and Speech**.
- Select a voice using the up and down arrows next to the Choose a Voice field. Tap Test to hear a sample of the chosen voice.

CUSTOMIZING THE GUIDANCE SCREEN

You can choose what useful information is displayed at the bottom of your screen when you are driving.

- Tap in the bottom right hand corner of the screen.
- Choose from Destination, Current Road, Next Crossroad, Next Major Road, Nearest Town, Speed & Distance, Altitude & Heading, and Latitude & Longitude.


Destination
Current Road
Next Crossroad
Next Major Road
Nearest Town
ETA & Distance
Speed & Distance
Altitude & Heading
Latitude & Longitude
ETA
12:02 a
DISTANCE
496 mi
Exit 362 - Keel
h)
0.9
mi
MENU
Hwy 401 (Macdonald-Cartier Freeway...

SETTING MAP STYLES

Tap **Menu > Settings > Map Styles.**

You can select from a range of industry leading map presentation styles and color themes using the Map Style list on the right of the screen. A preview is shown each time you select one, once you are happy with your selection tap OK. For more detail on changing the **Map Styles** see page 40.

CUSTOMIZING ROUTING OPTIONS

Once a destination has been entered the route screen will appear, showing you a preview map of the route. Select Routing to define a routing profile for the journey. For more details see **Preview your route** on page 23.

DISPLAY SCREEN OPTIONS

DRIVER SAFETY VIEW

We recommend you choose driver safety, which displays a simple turn instruction arrow with concise next turn instructions in large type. In driver safety mode, a map is only displayed as you approach a turn or are traveling below 10 mph.



Make a sharp right on US-206 South

ETA
2:18 a
DISTANCE
13.2 mi
0.7
mi
MENU
18 mph
13.2 mi

Adjusting the safety view
You can alter the settings of the driver safety view. See Adjusting the Safety View on page 42.

3D VIEW

This mode shows your current position, next turn and surrounding roads using a bird's eye view.



206
Duffy Place
ETA
2:48 a
DISTANCE
12.7 mi
0.2
mi
US-206 South
MENU
18 mph
12.7 mi

2D WHERE AM I

This mode displays your current location a 2D map.



Bunn Dr
ALK Technologies
206
ETA
2:48 a
DISTANCE
12.5 mi
3.2
mi
US-206 South (Stockton Street)
MENU
18 mph
12.5 mi

2D NEXT TURN

Displays your current location and auto zooms into the next turn on a 2D map.


Princeton
Princeton Township
Armo
John St
Bank St
Boudinot
Morven
Library
Green
Hodge
Maclean
Cleveland
US-206 South (Stockton Street)
MENU
18 mph
9.5 mi
ETA
2:49 a
DISTANCE
9.5 mi
0.3
mi

2D DESTINATION

This view shows your route from your current position to your destination.


295
641
583
29
571
614
569
Pennington
1
522
US-206 South (Stockton Street)
MENU
18 mph
10.8 mi
ETA
2:50 a
DISTANCE
10.8 mi
1.6
mi

ITINERARY

This view shows each direction and turn in a written list, including distances.



Turn Instruction	miles
60th Avenue Northwest (Route 4 East)	2.2
Route 22 South (41st Avenue Northwest)	1.6
US-14 East	1.4
US-14 South (US 52)	1.7
US-52 South (17th Avenue Southwest)	8.4

ETA
DISTANCE
852 air mi.
MENU
< 5 mph
852 air mi.

NIGHT MODE

Night mode can be activated on any of the display screen modes. It dims the GPS display to reduce glare and eye strain when driving at night. The ***SPOTTER*** will automatically switch to night mode based on the time and your location, or you can do it manually from the Driving Views menu.
Tap Menu > Next> Driving Views>

Next > Night Mode scroll to the nest page and select **Night Map**.



To switch off Night Mode, just select Day Mode.

You can also alter the day and night mode settings from the Map styles screen. See Setting Map Styles on page 40 for details.

ADVANCED

ADVANCED POI SEARCH

If you want to visit a specific POI without inputting the address, you can search the POI database and set it as a destination.

- Select **Menu > Destination > Points of Interest**



- Choose to select a category or search all. If you check the **Pick Category** box, tap the correct category. Tap **Next.**
- If you know the name of the place you want to visit, enter it here, or tap **Next**.
- Select a location option: choose from **Near Current Location**, **Along my route**, **In a City or Near an Address** to search for a related POI
- For **Current location** and **Along my route**, the POI list will be automatically generated. If you selected **In a City** or **Near an Address**, enter the name of the city or town nearest the POI you are searching for. Tap **Next**.
- The ***SPOTTER*** will then search the list of millions of POIs. When complete a list of the nearest matches will appear on screen.
- Highlight the correct one and tap details to view it on a map. The ***SPOTTER*** will also display the phone number for the POI if available.
- Tap **OK** and the ***SPOTTER*** will create a route from your current location to your selected POI.

ADJUSTING THE POI SETTINGS

You can choose when to have POIs shown on screen and the distance at which you are alerted to them by adjusting the POI settings.

- Tap **Menu > Settings > Next> POIs**.
- Enable the POIs by checking the box. Disable by un-checking.
- Choose to **Show POIs Always**, **Never** or **When Stopped** from the drop down menu.
- In the **Report POIs this far ahead** field, select a distance between 0.2 and 25 miles.
- Select whether to show POIs that are on your route or nearby it by checking one of the options.
- Select specific POI categories to display by checking the boxes.
- Tap **OK** to apply the settings and return to the Settings menu.

SELECTING A DESTINATION USING LAT AND LONG

If you know the latitude and longitude of your destination you can enter them directly.

- **Tap Menu > Destination** scroll to the second screen and tap **Coordinates**.
- Choose to set the latitude and longitude in Degrees Minutes Seconds, Decimal Degrees or Decimal Minutes.
- Enter a latitude and longitude in the appropriate format depending on which one you selected. The ***SPOTTER*** will take a few moments to find the point. When it is located a map will appear with the location pinpointed by a red arrow.
- Select **Drive** to begin navigating your route.

SETTING DETOURS

You can program your ***SPOTTER*** to make a detour on a part of the calculated route.

- Select **Menu > Detour**.
- From the Detour options, select **Avoid Roads**.
- An itinerary of your trip will appear. Click on the road you would like to avoid then select **Avoid Road**.
- The ***SPOTTER*** will take a few moments to plan an alternative to the selected road, and then announce any change in distance the new route will cause to your trip, and display a map of the new route.
- Tap **Accept** and the ***SPOTTER*** will begin directing you according to the new route.
- If you decide not to use the new route, select **Decline**. The ***SPOTTER*** will then return to your original route.

The ***SPOTTER*** will save the details of roads you wish to avoid. To clear the memory, select **Menu > Detour > Clear Avoided Roads**.

ENDING A DETOUR

If you are on a detour route and would like to return to the original trip tap **Menu > Detour > End Detour.**

OPTIMIZING STOPS

The ***SPOTTER*** has an Optimize Stops function, which will automatically rearrange the stops within a trip to create the most efficient order. When you have programmed a trip with more than 3 stops, tap Optimize. The ***SPOTTER*** will take a few seconds to reorder your stops for the most efficient route. Your start point and destination will not be altered. You can optimize up to 50 stops at once.

ENABLE FUEL CALCULATOR

The ***SPOTTER*** comes equipped with a fuel calculator for estimating the fuel cost of a trip. In the trip planning window click the **Options** button:

- To see fuel cost estimated when the trip is calculated, type in the **Vehicle Miles per Gallon** and **Cost per gallon.**
- To have break hours included in the trip ETA, select a **time interva**l and **break time.**
- When **Optimize Final Destination** is checked the position of the last stop on the destination list can be changed when the trip is optimized. (See previous section for more information.)

CHANGE YOUR ENTIRE TRIP

If you are unhappy with the entire route planned for you, tap **Menu > Detour > Alternate route**. The ***SPOTTER*** will compile a different route for you if a sensible alternative exists.

A map of the proposed detour will be displayed. Select **Accept** to agree or **Decline** to return to the previous route.

SETTING MAP PREFERENCES

You can also set up what sort of maps the ***SPOTTER*** uses. Tap **Menu > Settings > Map**. The available settings are:

- **Units**: Choose to display Miles or KM on your maps.
- **Map Rotation**: Choose **Heading Up** to always be travelling upwards on the screen, or select **North Up** to hold the map static as you travel along your route.
- **Stylus control:** Select **Box Zoom** or **Drag Map.**
- **General**: Choose whether to display turn restrictions by checking or un-checking the box.
- Tap **OK** to apply the settings and return to the Settings menu.

SETTING MAP STYLES

- Tap **Menu > Settings > Map styles.**

- Choose the default setting for the day or night mode from the list, using the arrow buttons. The options are **Automatic**, **Night** and **Day**.

  If you select **Automatic**, the ***SPOTTER*** will automatically switch to night mode when it starts to get dark, based on the current time and location.

  To change the setting, tap the down arrow below **Day/Night Mode**, to select between Day and Night, once you have made your selection tap **OK**.

  You can select from a range of industry leading map presentation styles and color schemes using the **Map Style**: list on the right of the screen. A preview is shown each time you select one, once you are happy with your selection tap **OK**.

SETTING ROUTE PREFERENCES

You can set up your preferences to best suit you. Tap **Menu > Settings > Routing**. The available settings are:

- **Vehicle type**: Choose from Automobile, RV, Motorcycle, Bicycle, Walking or Straight Line.

- **Routing type**: Choose whether you want to always an Economic route or Avoid Expressways.

- **Toll Roads**: Choose to Use, Always Avoid or Avoid if Possible all toll roads your route may encounter.

- **General**: Tick the boxes if you would like to a Scenic Route, to Avoid Ferries, to Avoid propane restricted Tunnels, and/or keep International Borders Open.

Tap **OK** to apply your new routing preferences.

Use an existing profile
To load an existing profile tap **Load Routing Profile** and select one of your previously saved ones or the Default profile. Click **OK** twice to return to the Settings menu and apply the profile.

SAVING A ROUTE PREFERENCE

To save a routing profile scroll to the bottom of the page and tap **Save as Routing Profile** when prompted enter a name for your profile and tap OK.

LOADING A SAVED ROUTING PROFILE

To load an existing profile tap **Load Routing Profile** and select one of your previously saved ones or the Default profile. Click **OK** twice to return to the Settings menu and apply the profile.

Edit your routing preference
Edit your routing preferences by loading a saved profile, changing the settings and resaving with the same name.

EDIT YOUR ROAD PREFERENCES

After a routing profile has been added, you may view Edit Road Preferences. Scroll to the bottom of the page and tap View/Edit Road Preferences. The available settings are:

- For each **road type**: Choose whether you want to **Strongly Avoid**, **Avoid**, **Neutral**, **Favor** or **Strongly Favor** when choosing a route.
- **Speed**: Select an appropriate speed for each road, you can increase or decrease the speed in increments of 5.

Note: It is not recommended to change the default route and road preferences as this will affect the route calculated and ETA shown.

CHECKING THE GPS STATUS

Tap **Menu > Settings > GPS > GPS Status**.

The GPS Status screen shows detailed information regarding the GPS fix and signal strength your ***SPOTTER*** uses for guidance.

From this screen you can see your current latitude and longitude position, the UTC time and date, your speed and your elevation (feet above sea level).

ADJUSTING YOUR SAFETY VIEW

Tap **Menu > Settings > Next> Driver Safety**. From here you can alter the settings of the Safety View in the following ways:

- **Display Map Near Turns**: Decide whether to show a 2D/3D zoomed map on the approach to each turn or always show the Driver Safety screen. Check the box for **Yes** to display the map or **No** not to.
- **When the Turn is Within**: If you selected **Yes** above, choose the distance before the turn you would like the map to be displayed. The distance can be set between 0.3 miles and 1 mile.
- **Map Type**: If **Display Map Near Turns** is set to **Yes**, select whether to use a 2D or 3D map when approaching turns.
- Tap **OK** to save your new settings and exit. Tap **Cancel** to discard your changes.

TRACK PLAYBACK

You can play back a previously completed trip.

- Tap **Menu > Settings> Next > Track Playback**.
- Select the trip from the list.
- Tap **Play** to start playback.
- Adjust the playback speed using the up and down arrows next to the Track Playback Speed field. The available speeds are between 1.O X and As Fast As Possible.
- To stop playback, tap **Stop**.
- To exit, tap **Cancel**.

ADJUSTING THE VOLUME

Tap **Menu > System > Next> Volume**.

Use the + and - symbols to increase or decrease the volume of the spoken instructions. To turn off the ‘tap’ sound which occurs when you touch the screen, uncheck the box marked **Enable sounds for taps**.

- Tap **Menu > Settings > Guidance**.
- Select at what distances your want the ***SPOTTER*** to speak to you when approaching a turn.
- Select what information you wish to be displayed on the customizable part of the screen, the options are **Destination, Current Road, Next Crossroad, Next Major Road, Nearest Town, Speed & Distance, Altitude & Heading, Latitude & Longitude**.
- Check the box to **Display Route Arrow**, or uncheck to remove.
- Tap **OK** to save your settings and exit. Tap **Cancel** to discard your changes.

SETTING THE LANGUAGE AND SPEECH

- Tap **Menu > Settings > Next> Next> Language and Speech**.
- Select your choice of language using the up and down arrows next to the **Choose a Language** field.
- Select a voice using the up and down arrows next to the **Choose a Voice** field. Tap **Test** to hear a sample of the chosen voice.

Street name text-to-speech
Not all voices have street name text-to-speech capabilities. Select a voice with an ***** next to the name if you want street names announced. Dale Jr’s voice does NOT announce street names.

ADJUSTING KEYBOARD SETTINGS

- Tap **Menu > Settings > Next > Next > Device**.
- Select the keyboard type of choice from the drop-down menu. The options are **Alphabetical, QWERTY, AZERTY**.
- Tap **OK** to save your settings and exit. Tap **cancel** to discard your changes.

PLAYING A DEMO

The ***SPOTTER*** contains a demonstration trip to a pre-defined destination. To view the demo:

- Tap **Menu > Next> Next> Play** scroll through and select **Play Demo.**
- Speed up by tapping **Faster** or slow down by tapping **Slower**.
- Tap **Close** to exit the demo mode.

MULTI-MEDIA FEATURES

In addition to superior GPS navigation, the ***SPOTTER*** GPS Navigator allows users to listen to music, watch movies, read e-books, and view photos stored on a memory card. The following sections will provide information on using the additional programs and features available.


GPS
08:36
GPS
Video
Music
Picture
E-Book
System Set

Do NOT remove the SD card while operating the multi-media features!

MEMORY CARD

The music, books, videos, and/or pictures used with these programs need to be stored on a storage or memory card (i.e. SD card).

SD cards may be purchased at most stores carrying electronic devices and come in a wide range of capacity. Please follow the directions that come with your card for saving items to an SD card.

INSERTING A MEMORY CARD

1. Locate the notched end of the memory card. This is the end to insert into the memory slot.
2. Locate the memory card slot on the right side of the ***SPOTTER***.
3. With the memory card label facing front (i.e. same side as the screen) and the notched end of the card at the top, gently slide the card into the device, until it locks into place.

When the card is locked in place, it will be even with the edge of the unit and not sticking out.

Memory cards work best when the contact points of the card (i.e. the metal parts) are clean and undamaged.

REMOVING A MEMORY CARD

1. To safely remove the memory card, exit out of any files being used from the memory card.
2. Gently press the memory card into the device until the lock disengages and the card pops out slightly.
3. Grabbing the edge of the card, carefully slide the memory card out of the unit and store in a safe place.

Removing the memory card while using it may corrupt the files contained on the card.

MOVIE VIEWER

The ***SPOTTER*** GPS Navigator can be used to watch movies and videos. It can play MP4, MPEG-1, AVI, WMV, ASF, 3GP and Divx files.

1. Copy the movie and/or video file you wish to view to a memory card.
2. Insert the memory card into the unit.
3. Tap the *Video* button to open the Video VIEWER screen.


VIDEO
Close/Exit Video
Search video files
Enter/Select

Video file 1.wmv
Video file 2.wmv
Video file 3.wmv

4. Double click on the desired video or highlight it and tap Enter to play the file. The video will begin.

   NOTE: It will take a few minutes to search the files if the video player hasn't been used for awhile


45:38/18:26
Play
Stop
Previous
Next
Full Screen
Volume
Video Progress
Close/Exit Video

MUSIC PLAYER

The music player enables you to turn your ***SPOTTER*** GPS Navigator into an MP3 player. It can play MP3, WMA, and PCM files.

1. Copy the desired music files to a memory card.
2. Insert the memory card into the unit.
3. Tap the Music button to open the MUSIC PLAYER screen.



MUSIC

No.	Song Name	Singer
01	Music 01	abc
02	Music 02	abc
03	Music 03	abc
04	Music 04	abc

Close/Exit Video

Search music files

Enter/Select

4. Double click on the desired music or highlight it and tap Enter to play the file. The music will begin.



Music progression

Volume

Return to Main Menu while listening to music

Stop **Previous** **Pause** **Next** **Loop**

E-BOOK READER

The ***SPOTTER*** GPS Navigator can be used to view texts, books and documents in TXT files.

1. Copy the TXT file you would like to read to a memory card.
2. Insert the memory card into the unit.
3. Tap the *E-Book* button to open the E-BOOK READER screen.


E-Book
Close/Exit E-Books
Search book files
Enter/Select

eBook 01.txt
eBook 02.txt
eBook 03.txt
eBook 04.txt

4. Double click on the desired book or highlight it and tap Enter to play the file. The book will appear.


Bookmark
Jump
Search
Previous
Next
● Auto
○ Manual
○ Big font
● Small Font
Page turning options
Font options

The Project Gutenberg EBook of History of the United States by Charles A. Beard and Mary R. Beard

This eBook is for the use of anyone anywhere at no cost and with almost no restrictions whatsoever. You may copy it, give it away or re-use it under the terms of the Project Gutenberg License included with this eBook or online at www.gutenberg.net.

Title: History of the United States
Author: Charles A. Beard and Mary R. Beard

BOOKMARK

The bookmark is useful when reading a lengthy book or article. It can be used to both mark and return to the last page read. Tap the bookmark button to enter the bookmark screen:


01
02
03
04
05
06
07
08
09
10
Jump
Save
Delete
Exit bookmark

Highlight the bookmark you would like to go to, then tap the jump button or tap save to save your current page as a bookmark.

JUMP TO THE APPOINTED PAGE

The jump feature can be used to return to a specific place when there is no bookmark set, but you know the page number. Tap the jump button to display the jump screen:


C
6
7
8
9
0
1
2
3
4
5

Enter the page number to jump to by tapping on the corresponding number. Use:

← to delete the previous number entered

C to delete all numbers entered

↵ after entering page number to jump to that page

SEARCH FOR SPECIFIC WORD OR PHRASE

Use the search feature to locate a term or phrase in your e-book or article. Tap the search button to bring up the search window:



● Check current page ○ Check all

Tap in the input box to bring up a keyboard. Use the keyboard to enter the term or phrase you are looking for, then tap check.

PHOTO VIEWER

The ***SPOTTER*** GPS Navigator can be used to view photos in JPEG, BMP, and PNG formats.

1. Copy the photo files for the pictures you would like to view to a memory card.
2. Insert the memory card into the unit.
3. Tap the *Photo* button to open the PHOTO VIEWER screen.


PHOTO
photo 01.JPEG
photo 02.JPEG
photo 03.JPEG
photo 04.JPEG

Close/Exit Photo

Search photo files

Enter/Select

4. Double click on the desired photo or highlight it and tap Enter to play the file. The photo will display.


○ Auto
○ Hand
1:1

Slideshow/ Manual

Previous

Next

Zoom In

Zoom Out

Change Ratio

Full Screen View

Dale Jr's dogs

SETTINGS MENU

The ***SPOTTER*** allows users to make changes to various settings on their device.



LANGUAGE

Click on the national flag corresponding to the desired language. The system will save automatically and return to the menu.

BACKLIGHT

The backlight feature enables you to adjust the brightness of the screen and designate the length of time to wait before shutting down the back light.

POWER

The *Power* button allows you to see the battery status and adjust length of the stand-by time to meet your needs.

SOUND

Sound allows you to adjust the volume of the unit as well as the screen sound made when a button is tapped.

TIME

The *Time* button enables you to modify the date and the time, select your time zone, and you can also enable and disable day light savings time.

SYSTEM

The *System* button enables you to view information specific to your unit, such as available memory, and to re-calibrate the touch screen.

FREQUENTLY ASKED QUESTIONS

Why won’t my unit turn on?

Check the power. Does the battery need to be charged? Plug into a power source and then try to turn on the device.

Why am I unable to get a GPS signal or fix?

The very first time you use the ***SPOTTER*** GPS navigator, it can take up to 10 minutes to initialize the GPS. After the first time, GPS reception should start within 1 minute of turning on the device. If the navigation device has been switched off for more than 1 week, the next initialization can take up to 5 minutes. For the GPS to properly receive satellite data it needs a clear view of the sky. The most common limitations to receiving GPS signals are urban canyons, tunnels and metallic surfaces. Most of the time, this isn’t an issue. If you are experiencing difficulty, place your unit near the rearview mirror.

Why does my unit sometimes make a popping or static like noise?

The popping/static noise comes from interference with cell phones. It doesn’t impact the unit or its performance. If the occasional noise is bothersome, either turn the cell phone off or move the unit further away from the phone.

Why does my unit not display the correct time?

The device will show the time once the device has a GPS signal. Please make sure you have the correct time set. To verify you have the time set correctly, go to **System Set>Time**.

In the Software, you can also check your time zone by selecting **Menu>Settings>Time Zone.**

Although I am receiving turn-by-turn instructions on-screen, it is not speaking to me. Why is that?

Check that the volume on your GPS is turned up. Go to **Menu > Settings > Volume**. If the volume is okay, check **settings>language & speech** to verify your voice selected is a Full-text voice. This is noted by an * next to the voice name.

Why does my unit sometimes miss announcing the street name?

You can change the turn warning by going to **Settings**>**Guidance**>Choose when you want the device to speak the turn. Also check **settings>language & speech** to verify your voice selected is a Full-text voice. This is noted by an ***** next to the voice name.
NOTE: Dale Jr’s voice is only available in turn by turn directions, and not Full text-to-speech.

My device provided me a route that was different than the one I would ordinarily expect the system to select. Why?

The ***SPOTTER*** relies on the quality of navigation software and maps, and the complex interaction between then. The Route Profile setting determines the routing. The **Quickest** Route setting relies on fast roads such as interstates and highways. This is not necessarily the shortest route. The **Shortest** Route setting relies on the shortest distance between two points, which may or may not be the fastest.

TECHNICAL SPECIFICATIONS

SPOTTER™
GPS NAVIGATOR

Physical & Performance:

Dimensions	105.5×67.2×4.95mm
Weight	190 g
Display size	4.3 in.
Display resolution	480×272 pixel
Screen type	Anti-glare LCD Touch screen
Battery	Built-in 1000Li-Ion Rechargeable
GPS module	SiRF Atlas III
RoHS	Yes
Audio Out	Built-in speaker Earphone jack

Navigation Features

- Predictive text data entry
- Voice prompts (e.g. "in ½ mile, turn right")
- Street name text-to-speech capabilities (e.g. "turn right on 1st Avenue")
- 2D map view
- 3D map view
- Safety map view
- Itinerary View
- Choice of route set-up
- Automatic re-route
- Route avoidance options
- Over 1.7 million Points of Interest
- Route Optimization
- Gas calculator

Maps & Memory

Processor	Centrality AT642 372MHz
Operating System	Win CE.NET 5.0
Memory	64M RAM 2G SD card (included)
Memory slot	SD card slot
Map data	Navteq
Preloaded maps	United States
Ability to add maps	Yes
Create & save multi-	Yes

Multi-media Features

Music Player	WMA, MP3
Movie Player	AVI, WMV, ASF, DAT, MPEG, MPG, MOV
E-Book Reader	TXT
Photo Viewer	JPEG, BMP

RightWay®

Note: Specifications are subject to change without notice.

SAFETY & WARRANTY INFORMATION

SAFETY INFORMATION

Use this navigation system at your own risk.

Caution! To prevent accidents, do not operate the navigation system while driving.

Caution! Do not look at the display unless it is absolutely safe to do so!

Caution! Traffic regulations have priority over any instructions from the navigation system.

Caution! Follow the instructions of the navigation system only when the circumstances and the road traffic regulations allow you to do so! The navigation system guides you to your destination even if you deviate from the calculated route.

Caution! Check that the unit is secured in the mount and adjusted properly before each journey.

Caution! The United States government operates the Global Positioning System (GPS) and is solely responsible for its accuracy and maintenance. Changes by the United States government may affect the accuracy and performance of all GPS equipment, including your personal navigation device.

Caution! Ordinances or laws may restrict use of certain abilities of your navigation device on public or private land.

CARE & SAFE KEEPING OF THE *SPOTTER* GPS

- Protect the unit from moisture. It is not waterproof and is not protected against water damage. The warranty does not cover water damage.
- Do not open the unit's casing under any circumstances.
- Do not attempt to replace the battery. For problems related to the battery, contact Customer Support.
- Do not expose the unit to extreme heat or cold. This may damage the device or impair its function.
- Use only the charger provided or one that has been approved by the manufacturer.
- To clean the screen of the ***SPOTTER***, use a dry cloth. Paper towels will scratch the screen.

LIABILITY

RightWay GPS, its dealers, suppliers and distributors disclaim all liability for any use of this product in any way that may cause accidents, damage or that may violate the law.

RightWay GPS, its dealers, suppliers and distributors disclaim all liability for any use of this product in delivering medical aid, transporting of medical patients and/or equipment, or transporting medical emergency victims. Do NOT use this product during the time of local, state or national emergencies. If you wish to obtain versions of a navigation system optimized for us in medical emergencies, please contact Transplant GPS.

When using navigation aids, both hardware and software, in a vehicle, it is your sole responsibility to place, secure, and use these aids in a manner that will not cause accidents, personal injury, or property damage, or in any manner obstruct your view. You, the user of this product, are solely responsible for observing safe driving practices.

Rightway® is a registered trademark of Transplant GPS, Inc.

NASCAR ® is a registered trademark of The National Association for Stock Car Auto Racing, Inc.

©2009 Hendrick Motorsports, LLC. The name, likeness and signature of Dale Earnhardt, Jr. and the likeness of the #88 Amp Energy/National Guard Chevrolet are used with the permission of Hendrick Motorsports, LLC and JR Motorsports, LLC. AMP ENERGY is a trademark of PepsiCo, Inc.

END USER'S LICENSE AGREEMENT

END-USER LICENSE AGREEMENT FOR COPILOT® SOFTWARE Please read the following agreement ("License") carefully.

Acceptance: Installation or use of the enclosed ALK Technologies, Inc. ("ALK") software (the "Software") on your device constitutes your acceptance of these terms. If you do not agree to the terms of this License, you must immediately delete the Software from your device and destroy any copies you made of the Software and of any written materials relating to the Software, and promptly return the Software and, if bought as part of a package, any associated devices to your retailer for a refund.

License: ALK grants you, as an individual, a non-exclusive, non-transferable right and license to install and use one copy of the Software on a single device at a time. If your Software includes CoPilot Central, you may install and use the CoPilot Central portion on a different device than the CoPilot portion. Your license to use the Software is subject to you complying with the terms of this License. A license is required for each installation of the Software, unless the Software is (i) installed temporarily on a computer during the repair or maintenance of the device on which the Software is normally installed and (ii) is immediately deleted from such device as soon as those repairs or maintenance are complete. You may make one copy of the Software for backup purposes only.

Copyright: United States copyright law and international treaty provisions protect the Software. You agree that no title to the intellectual property in the Software is transferred to you. You further acknowledge that title and ownership rights will remain the exclusive property of ALK, and you will not acquire any rights to the Software except as expressly set out in this license. You agree that any copies of the Software will contain the same proprietary notices that appear on and in the Software. Prohibited Use: Unless you have ALK's prior written permission, you may not (i) use, copy, modify, alter, or transfer the Software or accompanying documentation, except as expressly permitted in this License; (ii) translate, disassemble, decompile, or reverse engineer the Software (iii) sublicense or lease the Software or its documentation; or (iv) use the Software in a multi-user or networked environment or on a rental basis or in a time-sharing or computer service business.

Limited Warranty: ALK warrants that the Software will perform substantially in accordance with the accompanying written materials for a period of 30 days from the date of purchase. Any implied warranties relating to the Software are limited to such 30 day period provided that limitation is permitted by applicable law.

End-User Remedies: If the Software does not conform to the "Limited Warranty" above, ALK's entire liability and your sole and exclusive remedy will be, at ALK's option, either to (i) correct the error, or (ii) help you work around the error, or (iii) accept a return and issue a refund through your retailer. The Limited Warranty is void if failure of the Software has resulted from your fault, abuse, or misapplication. If we correct an error in the Software for you, then the unexpired portion of the Limited Warranty period as at the date you informed us of the error will apply to the corrected software once you have received the corrected version. NO OTHER WARRANTIES: EXCEPT AS SET OUT IN THE LIMITED WARRANTY, ALK DOES NOT WARRANT THAT THE SOFTWARE IS ERROR FREE. ALK DISCLAIMS ALL OTHER WARRANTIES WITH RESPECT TO THE SOFTWARE, WHETHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OF THIRD PARTY RIGHTS. Some jurisdictions do not allow the exclusion of implied warranties or limits on how long an implied warranty may last, or an exclusion of incidental damages. This means the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights depending on your country. No Liability for indirect loss: In no event will ALK be liable to you for any loss of profit, wasted time, lost business or for any incidental, or indirect loss of any kind arising out of the performance or use of the Software, even if ALK has been advised of the possibility of such damages.

Termination: Without prejudice to its other rights, ALK may terminate this License if you fail to comply with these terms and conditions. In that situation, you must destroy all copies of the Software.

Limitations on Export: You hereby expressly agree not to export or re-export the Software, in whole or in part, in violation of any export laws or regulations of the United States. DISCLOSURE FOR PRODUCTS CONTAINING CANADIAN POSTAL CODE AND/OR CANADIAN STREET-LEVEL DATA: Based on Computer File(s) licensed from Statistics Canada. © Copyright, HER MAJESTY THE QUEEN IN RIGHT OF CANADA, as represented by the Minister of Industry, Statistics Canada 2003. ALK Technologies, Inc. is an Authorized User of selected Statistics Canada Computer File(s) and Distributor of derived Information Products under Licensing Agreement 6147. No confidential information about an individual, family, household, organization or business has been obtained from Statistics Canada.

U.S. Government Restricted Rights: The Software is provided with restricted and limited rights. Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in the appropriate subparagraphs of the Commercial Computer – Restricted Rights clause at 48 C.F.R. 52.227-19 or in the appropriate subparagraphs of the Rights in Technical Data and Computer Software clause at 252.227-7013 of the Defense Federal Acquisition Regulations. The Copyright to the Software is held by ALK Technologies, Inc., 1000 Herrontown Road, Princeton, NJ 08540 USA. Choice of Law: This License is governed by the laws of England.

END USER LICENSE FOR SPEECH PLAYBACK Please read the following agreement ("License") carefully.

This license applies to the speech playback function included in your Software, if any. Copyright (c) 2002, Xiph.org Foundation. Neither the name of the Xiph.org Foundation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission. THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS ``AS IS'' AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE FOUNDATION OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Personal Use Only. You agree to use this Data together with COPILOT for the solely personal, non-commercial purposes for which you were licensed, and not for service bureau, time-sharing or other similar purposes. Accordingly, but subject to the restrictions set forth in the following paragraphs, you may copy this Data only as necessary for your personal use to (i) view it, and (ii) save it, provided that you do not remove any copyright notices that appear and do not modify the Data in any way. You agree not to otherwise reproduce, copy, modify, decompile, disassemble or reverse engineer any portion of this Data, and may not transfer or distribute it in any form, for any purpose, except to the extent permitted by mandatory laws.

Restrictions. Except where you have been specifically licensed to do so by ALK, and without limiting the preceding paragraph, you may not (a) use this Data with any products, systems, or applications installed or otherwise connected to or in communication with vehicles, capable of vehicle navigation, positioning, dispatch, real time route guidance, fleet management or similar applications; or (b) with or in communication with any positioning devices or any mobile or wireless connected electronic or computer devices, including without limitation cellular phones, palmtop and handheld computers, pagers, and personal digital assistants or PDAs.

Warning. The Data may contain inaccurate or incomplete information due to the passage of time, changing circumstances, sources used and the nature of collecting comprehensive geographic data, any of which may lead to incorrect results.

No Warranty. This Data is provided to you “as is,” and you agree to use it at your own risk. ALK and its licensors (and their licensors and suppliers) make no guarantees, representations or warranties of any kind, express or implied, arising by law or otherwise, including but not limited to, content, quality, accuracy, completeness, effectiveness, reliability, fitness for a particular purpose, usefulness, use or results to be obtained from this Data, or that the Data or server will be uninterrupted or error-free.

Disclaimer of Warranty: ALK AND ITS LICENSORS (INCLUDING THEIR LICENSORS AND SUPPLIERS) DISCLAIM ANY WARRANTIES, EXPRESS OR IMPLIED, OF QUALITY, PERFORMANCE, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT. Some States, Territories and Countries do not allow certain warranty exclusions, so to that extent the above exclusion may not apply to you.

Disclaimer of Liability: ALK AND ITS LICENSORS (INCLUDING THEIR LICENSORS AND SUPPLIERS) SHALL NOT BE LIABLE TO YOU: IN RESPECT OF ANY CLAIM, DEMAND OR ACTION, IRRESPECTIVE OF THE NATURE OF THE CAUSE OF THE CLAIM, DEMAND OR ACTION ALLEGING ANY LOSS, INJURY OR DAMAGES, DIRECT OR INDIRECT, WHICH MAY RESULT FROM THE USE OR POSSESSION OF THE INFORMATION; OR FOR ANY LOSS OF PROFIT, REVENUE, CONTRACTS OR SAVINGS, OR ANY OTHER DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF YOUR USE OF OR INABILITY TO USE THIS INFORMATION, ANY DEFECT IN THE INFORMATION, OR THE BREACH OF THESE TERMS OR CONDITIONS, WHETHER IN AN ACTION IN CONTRACT OR TORT OR BASED ON A WARRANTY, EVEN IF ALK OR ITS LICENSORS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Some States, Territories and Countries do not allow certain liability exclusions or damages limitations, so to that extent the above may not apply to you.

Export Control. You agree not to export from anywhere any part of the Data provided to you or any direct product thereof except in compliance with, and with all licenses and approvals required under, applicable export laws, rules and regulations.

Entire Agreement. These terms and conditions constitute the entire agreement between ALK (and its licensors, including their licensors and suppliers) and you pertaining to the subject matter hereof, and supersedes in their entirety any and all written or oral agreements previously existing between us with respect to such subject matter.

Governing Law. The above terms and conditions shall be governed by the laws of the Netherlands, without giving effect to (i) its conflict of laws provisions, or (ii) the United Nations Convention for Contracts for the International Sale of Goods, which is explicitly excluded. You agree to submit to the jurisdiction of the Netherlands for any and all disputes, claims and actions arising from or in connection with the Data provided to you hereunder.

Restrictions. Except where you have been specifically licensed to do so by ALK, and without limiting the preceding paragraph, you may not (a) use this Data with any products, systems, or applications installed or otherwise connected to or in communication with vehicles, capable of vehicle navigation, positioning, dispatch, real time route guidance, fleet management or similar applications; or (b) with or in communication with any positioning devices or any mobile or wireless connected electronic or computer devices, including without limitation cellular phones, palmtop and handheld computers, pagers, and personal digital assistants or PDAs.

Warning. The Data may contain inaccurate or incomplete information due to the passage of time, changing circumstances, sources used and the nature of collecting comprehensive geographic data, any of which may lead to incorrect results.

No Warranty. This Data is provided to you “as is,” and you agree to use it at your own risk. ALK and its licensors (and their licensors and suppliers) make no guarantees, representations or warranties of any kind, express or implied, arising by law or otherwise, including but not limited to, content, quality, accuracy, completeness, effectiveness, reliability, fitness for a particular purpose, usefulness, use or results to be obtained from this Data, or that the Data or server will be uninterrupted or error-free.

Disclaimer of Warranty: ALK AND ITS LICENSORS (INCLUDING THEIR LICENSORS AND SUPPLIERS) DISCLAIM ANY WARRANTIES, EXPRESS OR IMPLIED, OF QUALITY, PERFORMANCE, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT. Some States, Territories and Countries do not allow certain warranty exclusions, so to that extent the above exclusion may not apply to you.

Disclaimer of Liability: ALK AND ITS LICENSORS (INCLUDING THEIR LICENSORS AND SUPPLIERS) SHALL NOT BE LIABLE TO YOU: IN RESPECT OF ANY CLAIM, DEMAND OR ACTION, IRRESPECTIVE OF THE NATURE OF THE CAUSE OF THE CLAIM, DEMAND OR ACTION ALLEGING ANY LOSS, INJURY OR DAMAGES, DIRECT OR INDIRECT, WHICH MAY RESULT FROM THE USE OR POSSESSION OF THE INFORMATION; OR FOR ANY LOSS OF PROFIT, REVENUE, CONTRACTS OR SAVINGS, OR ANY OTHER DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF YOUR USE OF OR INABILITY TO USE THIS INFORMATION, ANY DEFECT IN THE INFORMATION, OR THE BREACH OF THESE TERMS OR CONDITIONS, WHETHER IN AN ACTION IN CONTRACT OR TORT OR BASED ON A WARRANTY, EVEN IF ALK OR ITS LICENSORS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Some States, Territories and Countries do not allow certain liability exclusions or damages limitations, so to that extent the above may not apply to you.

TRANSPLANT GPS, INC. LIMITED WARRANTY

Hardware: Transplant GPS, Inc. warrants to the original end user (i.e. Customer) that this product will be free from defects in workmanship and materials, for one year from the date of original purchase from Transplant GPS, Inc. The provisions of this warranty shall not apply if, in Transplant GPS, Inc.’s judgment, the product has been subject to misuse or neglect, improper installation, damaged in an accident, or repaired or altered in any way that adversely affects its performance and reliability. Transplant GPS, Inc.’s sole obligation under this express warranty shall be, at Transplant GPS, Inc.’s option, to replace the product or part with a comparable product or part, repair the product or part, or if neither repair nor replacement is reasonably available, Transplant GPS, Inc. may, in its sole discretion, refund to Customer the purchase price paid for the product or part. Replacement products or parts may be new or reconditioned. Transplant GPS, Inc. warrants any replaced or repaired product or part, and any hardware upgrade to which Customer is entitled under an agreement between Customer and Transplant GPS, Inc. for a period of ninety (90) days from shipment, or through the end of the original warranty, whichever is longer. All products or parts that are replaced become the property of Transplant GPS, Inc. This warranty does not cover products sold AS IS or WITH ALL FAULTS.

Obtaining Warranty Service: Customer must contact Transplant GPS, Inc. within the applicable warranty period to obtain warranty service authorization. Dated proof of original purchase from Transplant GPS, Inc. or its authorized reseller will be required. Transplant GPS, Inc. is not responsible for Customer products or parts received without a warranty service authorization. Products or parts shipped by Customer to Transplant GPS, Inc. must be sent prepaid and packaged appropriately for safe shipment, and it is recommended that they be insured or sent by a method that provides for tracking of the package. THIS WARRANTY SHALL NOT BE EXTENDED, ALTERED OR VARIED EXCEPT BY A WRITTEN INSTRUMENT DULY SIGNED BY TRANSPLANT GPS, INC. WARRANTIES EXCLUSIVE. IF THIS PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, CUSTOMER‟S SOLE REMEDY FOR BREACH OF THAT WARRANTY SHALL BE REPLACEMENT OR REPAIR OF THE RODUCT OR PART OR REFUND OF THE PURCHASE PRICE PAID, AT TRANSPLANT GPS, INC.‟S DISCRETION. THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES (OR CONDITIONS), EXPRESSED OR IMPLIED, INCLUDING (WITHOUT LIMITATION), ANY WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, OR FITNESS FOR A PARTICULAR PURPOSE. TRANSPLANT GPS, INC. SHALL NOT BE LIABLE FOR LOSS OF PROFITS OR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES WHICH THE PURCHASER MAY SUSTAIN. IN NO EVENT SHALL TRANSPLANT GPS, INC.‟S LIABILITY EXCEED THE PURCHASE PRICE OF THE DEFECTIVE PRODUCT. TRANSPLANT GPS, INC. NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE OR USE OF ITS PRODUCTS. TRANSPLANT GPS, INC. SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS

TESTING AND EXAMINATION DISCLOSE THAT THE ALLEGED DEFECT OR MALFUNCTION IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER‟S OR ANY THIRD PERSON‟S MISUSE, NEGLECT, IMPROPER INSTALLATION OR TESTING, 25 UNAUTHORIZED ATTEMPTS TO OPEN, REPAIR, OR MODIFY THE PRODUCT, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OTHER HAZARDS, OR ACTS OF GOD. THIS WARRANTY DOES NOT COVER PHYSICAL DAMAGE TO THE SURFACE OF THE PRODUCT, INCLUDING CRACKS OR SCRATCHES ON OUTSIDE CASING. THIS WARRANTY DOES NOT APPLY WHEN THE MALFUNCTION RESULTS FROM THE USE OF THIS PRODUCT IN CONJUNCTION WITH ACCESSORIES, OTHER PRODUCTS, OR ANCILLARY OR PERIPHERAL EQUIPMENT AND TRANSPLANT GPS, INC. DETERMINES THAT THERE IS NO FAULT WITH THE PRODUCT ITSELF. THIS WARRANTY DOES NOT APPLY TO ANY MALFUNCTION OR FAILURE OF THE PRODUCT OR PART DUE TO ANY COMMUNICATION SERVICE CUSTOMER MAY SUBSCRIBE TO OR USE WITH THE PRODUCT.

Limitation of Liability: TO THE FULL EXTENT ALLOWED BY LAW, TRANSPLANT GPS, INC. ALSO EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF THIS PRODUCT, EVEN IF TRANSPLANT GPS, INC. OR ITS AUTHORIZED RESELLER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, AND LIMITS ITS LIABILITY TO REPLACEMENT, REPAIR, OR REFUND OF THE PURCHASE PRICE PAID, AT TRANSPLANT GPS, INC.‟S DISCRETION. THIS DISCLAIMER OF LIABILITY FOR DAMAGES WILL NOT BE EFFECTED IF ANY REMEDY PROVIDED HERE-IN SHALL FAIL OF ITS ESSENTIAL PURPOSE.

Disclaimer: Some countries, states, or provinces do not allow the exclusion or limitation of implied warranties or the limitation of incidental or consequential damages for certain products supplied to consumers, or the limitation of liability for personal injury, so the above limitations and exclusions may be limited in their application to you. When the implied warranties are not allowed to be excluded in their entirety, they will be limited to the duration of the applicable written warranty. This warranty gives you specific legal rights which may vary depending on local law.

Governing Law: This Limited Warranty shall be governed by the laws of the State of Minnesota, U.S.A. excluding its conflicts of laws principles and excluding the United Nations Convention on Contracts for the International Sale of Goods.

FCC PART 15 COMPLIANCE STATEMENT

This device is in conformance with Part 15 of the FCC Rules and Regulations for Information Technology Equipment. Operation of this product is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

CUSTOMER SERVICE

At RightWay we believe that the customer deserves the best possible service and support. We look forward to assisting you in making the most of your RightWay product.

On-Line

www.RightWayGPS.com

E-Mail

All e-mails will be answered within 2 business days.

Technical Support	contact Support@RightWayGPS.com for help trouble shooting, repair requests, ask questions about warranty
Customer Service	contact Service@RightWayGPS.com for help with recent purchase such as order status, delivery information, billing questions, returns and other order related issues
Sales Inquiries	contact Sales@RightWayGPS.com for help finding the RightWay product right for you, purchasing information

Telephone

Telephone:	(507) 529-1441
Service Hours:	Monday through Friday, 8:30 a.m. to 5 p.m. CST (except National holidays)

Snail Mail

Transplant GPS, Inc.
5050 75th Avenue NW
Byron MN 55920

SPOTTER™
GPS NAVIGATOR

Dale Jr™ EDITION

NATIONAL GUARD
88
IMPALA SS

RightWay®

NASCAR®